



Hazchem

40 Litre Spill Kit

Part #: SK40-HZE

1. Assess the spilt liquid and review its Material Safety Data Safety Sheet before applying any absorbent. This assists in ensuring all appropriate safety precautions are adhered to, including the use of suitable PPE equipment.
2. Create a barrier around the spill using Hazchem Containment Booms or Containment Socks
3. Cover the spill with the loose Hazsorb absorbent
4. Using a stiff broom, sweep the loose absorbent over the spill area
5. If there still appears to be free liquid visible (if the spilt liquid and absorbent mix does not appear dry) or if there remains an oily film on the surface, apply additional loose Hazsorb absorbent
6. Use Hazchem pads to wipe clean any area or equipment not cleaned by the loose absorbent.
7. Place all saturated absorbent products in the waste disposal bag provided and dispose of in accordance with local government regulations
8. Complete an incident report
9. Complete an inventory then replace all used spill kit items

Contents

	Orange PVC Spill Kit Bag	1
2309	Spillsmart Poly Pads Hazchem - 48cm x 43cm x Heavy Weight - Dimpled & Perforated	20
HAZ-7.5	Spillsmart Hazsorb 7.5lt bag	1
2315-1.2	SpillSmart Polypropylene Absorbent Socks – Hazchem – 75mm x 1.2m	1
3221	Pair of Nitrile Gloves	1
2321	Spillsmart Contaminaited Waste Bags - 450mm x 720mm	3